



Retro fit Laptop Lock-Up® LL-10 Base

- 1) Four Hex Screws and Four Rivets must be removed before the leg/base assembly can be removed from the cabinet chassis.
- 2) Using a 3/16" drill bit, drill out the four rivets. Two are located on the rear of the cabinet approximately 8" above the two rear hex screws. The other two rivets are located on the front of the cabinet 8" above the two front hex screws, behind a drawer front.
- 3) After the rivets have been removed loosen the four hex screws. Three may be removed at this time, but the fourth should remain in place until the cabinet has been laid on one of its sides.
- 4) Lay protective material (cardboard, blanket etc.) on the ground next to the cabinet and carefully lower the cabinet onto one of its sides. Remove the last hex screw.
- 5) The leg/base assembly can be removed from the cabinet and the new Leg/base assembly inserted. Install at least one of the hex screws into the cabinet. Do not tighten the hex screws at this time.
- 6) Stand the cabinet up and install the remaining hex screws, do not tighten them at this time.
- 7) Replace the four rivets. These four rivets provide additional rigidity to the cabinet.
- 8) Tighten the four hex screws.