



SMARTSTORAGE™ WM-100 Mounting Instructions

- 1) The SS WM-100 has 7 sets of mounting holes located across the rear panel of the unit, and have a key hole with a round hole configuration.
- 2) The sets of mounting holes are set 8" apart. This will allow several mounting holes to line up with, either 16" on center or 24" on center, wall studs.
- 3) The holes are designed to use a # 10 screw.
- 4) It is strongly recommended that the cabinet be mounted to the wall surface using no less than three securely anchored screws (more than three when possible).
- 5) These three screw locations should be into solid surfaces (i.e. wood, metal, wall stud etc.)
- 6) Once the solid mounting positions have been located secure the mounting screws to the wall leaving the screw head about ¼" from the wall surface.
- 7) Hang the cabinet onto the mounting screws through the keyholes.
- 8) Tighten the screws, securing the cabinet firmly to the wall.
- 9) Place additional screws into the solid mounting surface through the round holes directly below the key holes that were used for mounting the cabinet. This will prevent the cabinet from being lifted up off of the mounting screws.

*** Should you have any questions please contact: Static Safe™ Products Company

Customer Service, Toll Free 1-866-937-6391